

# AK275/AS275 TOTE SPRAY SYSTEM

## QUICKSTART GUIDE

1. Prime your spray system with water by filling your suction hose feed that goes from the side of the pump to the tote with water while your spray system is turned off. The goal is to get rid of the air in the suction feed going to the side of the pump to the tote so that the pump can prime properly.
2. Connect the suction hose that is now full of water to the bottom of your tote. Make sure that air is not entering the suction feed.
3. Start your spray system up in re-circulation mode so that the unit removes all air and creates complete prime. Run it this way for 3 to 4 minutes. Do NOT over circulate/agitate the sealer in the tote or the sealer will get foamy with air pockets which can impact the application of the sealer as well as affect the pressure in the pump.
4. Turn the ball valve from circulate to spray mode and start applying sealer to the surface evenly.

### RECOMMENDED VIDEOS TO WATCH

How to mix sealer in drums and prime your spray system



<https://www.youtube.com/watch?v=uSdk7wT7qeo&t=75s>

Sealcoat application video



<https://www.youtube.com/watch?v=Zq62BAnPzBQ&t=156s>

 **ASPHALT KINGDOM**

1-866-399-5562

 **Action Seal**  
CANADA

1-855-554-4386