

AK55/AS55 DRUM SPRAYER

QUICKSTART GUIDE

1. Please prime your spray system with water by filling your drum kit suction feed with water while your spray system is turned off. Then put the drum kit into an empty drum or garbage can of water with about 20 gallons of water. Make sure that air is not entering the suction feed.
2. Start your spray system up in re-circulation mode so that the unit removes all air and creates complete prime. Run it this way for a minute or so.
3. Turn your spray system to spray mode and practice spraying water for the first time. Turn your spray system off. Once comfortable, remove the lid on your drum and mix the sealer thoroughly so that the sealer is blended like a tomato soup consistency.
4. Fill your suction feed with water and then place it into the drum. Try to avoid any air from entering the suction feed as much as possible. This assures your pump will be primed and will create suction. Repeat step #2 to prime.
5. Turn your spray system to spray mode and start applying sealer to the surface evenly.

RECOMMENDED VIDEOS TO WATCH

How to mix sealer in drums and prime your spray system



<https://www.youtube.com/watch?v=uSdk7wT7qeo&t=75s>

Sealcoat application video



<https://www.youtube.com/watch?v=Zq62BAnPzBQ&t=156s>

**ASPHALT KINGDOM**

1-866-399-5562

**Action Seal**
CANADA

1-855-554-4386